




# MANOGRAFO T – MANUALE D’ISTRUZIONI

## T RECORDER – USER MANUAL



### Sostituzione diagrammi:

I diagrammi vanno fissati al tamburo con l'apposita asta ferma diagrammi. I diagrammi mostrano sul bordo inferiore l'avanzamento giornaliero e sul bordo superiore quello settimanale. I diagrammi recano il numero che li distingue in funzione delle scale normalizzate

### Cambio Velocità

Il registratore viene impostato default la registrazione giornaliera. per modificare l'impostazione in settimanale ecco come fare:

- Sollevare il coperchio . **Attenzione a non danneggiare l'asta porta pennino**
- Svitare il pomolo del tamburo.
- **Attenzione filetto sinistro**
- Sfilare il tamburo
- capovolgere l'ingranaggio fissato all'interno del tamburo
- richiudere procedendo al inverso

### Charts substitution:

Charts must be fixed to the drum with dipstick diagrams stops. The charts show the daily timing in the lower edge and the weekly on the top edge. Charts shows the number according the range.

### Changing gearbox

The recorder is set to daily as default. To change the setting in weekly here's how:

- Lift the cover. **Careful not to damage the rod pen holder**
- Turn the nut on drum clockwise .
- **Careful left thread**
- Leave the drum.
- upsidedown the gear inside the drum
- Close everything carefully going opposite

I dati, le misure e le informazioni riportate potranno essere cambiate in qualsiasi momento da Bart S.r.l. senza preavviso.  
The data, measurements and information given in this datasheet may be changed at any time by Bart S.r.l. without prior notice.

Bart srl

Via Magistretti, 9 - 20128 Milano Italy - Tel. +39 02 27206577 - Fax +39 02 25902084 - [www.bart-e.com](http://www.bart-e.com)  
info@bart-e.com - P.I. 03015200151 - Cap. Soc. euro 36.400,00 - CCIAA MI 931842 - Trib. MI 234691/3874