

### ATTENZIONE

- **Prima di procedere all'installazione o alla manutenzione dello strumento, leggere le istruzioni riportate di seguito.**
- L'installazione dello strumento deve essere eseguita solo dopo aver accertato l'idoneità delle caratteristiche dello strumento ai requisiti dell'impianto e del fluido di processo. In particolare, le parti dell'elemento misuratore a contatto con il fluido di processo devono essere di materiale adatto al fluido stesso.
- L'installazione e la manutenzione dello strumento deve essere eseguita esclusivamente da personale qualificato.

### INSTALLAZIONE

Prima di mettere in pressione l'impianto chiudere il dado (1) mantenendo in movimento la leva (2) di apertura e chiusura in modo che non si blocchi il rubinetto

### ATTENTION●

- **Before installing or upkeeping the gauge, read the following instructions.**
- The installation of the gauge must be done only after checking the characteristics of the gauge with the plant and the process fluid. The parts of the manometers wetted by fluid should be of chemical material suitable for the operating conditions of the fluid itself.
- The installation and upkeeping of the gauge must be done only by qualified personnel

### INSTALLATION

Before pressurise the installation close the nut (1) moving the lever (2) so that the handle does not .lock itself

